





QUICK TECH



QUICK TECH has been conceived to join two worktops or panels together.

It consists of two parts:


- main body with tightening dowel M8x64, M8x100 or M8x150;
- round cap to suit the dowel head.


The installation is fast and simple as the two parts don't fall when placed in position.


The fastening becomes easier by using an S6 mm allen wrench, or even better, a cordless driver.

It is suitable for worktops and panels minimum 25 mm thick.






























QUICK TECH























DRILL BIT FOR QUICK TECH
















SYMBOLS AND FINISHES LEGEND

SYMBOLS



= SHELF SAFELY LOCKED DURING TRANSPORTATION AND AT HOME.



= ANTI-TURNOVER LOCKING SYSTEM



= NORMS / PATENTS



= PHILLIPS / POZIDRIV



= WITH BUFFER



= PART NO.



= BLADE SLOT



= WITH MAGNET



= PCS. PER PACKAGE



= COMBI SLOT



= NEWTON



= CAPACITY LOADING



= HEXALOBULAR SOCKET

= HEXAGONAL SOCKET



= FRICTION



= WOOD / GLASS THICKNESS



= COUNTERSUNK HEAD



= AUTOMATIC



= HOLE DIAMETER



= PAN HEAD



= DROP DOWN



= DIAMETER



= FLANGE HEAD

= FLAT HEAD



= STANDARD HINGE



= HEIGHT

= LENGTH



= TRILOBULAR SCREW



= KIMANA HINGE



= RIGHT VERSION



= SELF-TAPPING SCREW



= FLAP HINGE



 $= \mathsf{LEFT} \; \mathsf{VERSION}$



= EURO THREAD



 $= {\sf WITH} \; {\sf SPRING}$



= SETTING CODE



= METRIC THREAD



= WITHOUT SPRING



= PCS. PER PAD



= PRE-INSERTED SCREW



= REVERSED SPRING



= CUT ON REQUEST



= PRE-INSERTED SCREW AND SPREADING BUSH




= WITH FLANGE



= SELF ADHESIVE

NOTE: Printing errors and omissions may exist despite our best efforts to ensure accurancy. We reserve the right to alter specifications without notice.

MATERIALS



$$\left(ST\right) = Steel$$

$$\left(\mathsf{BR}\right) = \mathsf{Brass}$$



$$(WD) = Wood$$



+ (EP) = other engineering plastic available on request








FINISHES



= OTHER FINISHES AVAILABLE ON REQUEST

PART NO.	FINISHES	PART NO.	FINISHES	PART NO.	FINISHES
00	Insignificant finish	IF	Grey 7	XE	Inox
AA	Natural	IJ	Light Grey	YA	Nickel-plated
AB	White	IL	Grey 20	YC	Matt Nickel-plated
AE	White 9010	IN	Grey met. 26	YD	Satin-finished Nickel-plated
EA	Black	JG	Aluminium 5	YQ	Black Nickel
EC	Matt Black	JL	Aluminium PE 11	Z 9	Black Zinc
EE	Anthracite	JM	Aluminium RAL 9006	ZN	Zinc-plated
EW	Grey 9007	КВ	Bright Chrome	ZQ	Bright Gold
FU	Gunmetal	КС	Matt Chrome	ZZ	Clear/Transparent
FV	Gunmetal V52	LD	Brown 8019		
GR	Zamak Raw	RO	Red		
НА	Brass-Plated	UT	T-Met 9007		
НН	Tropicalized	UZ	T-Met		
HL	Raw Brass	WA	Bronzed		
НХ	Graphite	WI	Burnished		
IA	Grey	XD	Satin-finished Steel		





www.italian a ferramenta.com